

Load and Unload Pallets From ONE Side



- Access whole pallet from ONE side
- Load and unload pallets efficiently
- No need to rotate pallets
- Straddles entire pallet
- Move drums easily
- Simple to operate
- Quick to use
- No electrical parts
- Available air storage tank onboard
- Operate without hose connection
- Quick connect fitting to recharge tank
- Air operated (AC compressor optional)
- Lift mechanism pivots to grab left or right drum
- Handle your plastic, fiber or steel drums

This free-standing, manually propelled model is specially designed to load and unload pallets. Since this unit is able to straddle a four drum pallet, as well as bridge or go over the pallet (as shown in the picture), the user is able to access the whole pallet load from **one** side of the pallet. The unique design of this pallet server means that there is no longer the inconvenience of having to rotate the pallet to get to the drums at the back or shift the handler to approach the pallet from all four corners.

The unit uses a pneumatic cylinder for lifting the drum. Onboard air-storage tank can hold enough air to lift and move a number of drums (weight and lift range effect how many) while disconnected from air supply line.

There are 4" (10.2 cm) swivel casters in the rear and 8" (20.3 cm) fixed wheels in the front. This unit is designed to handle virtually any rimmed drum whether steel, plastic or fiber.

A tiller allows the operator to pivot the gripping mechanism to pick a drum at the left or right corner of the pallet.

750 Series Pallet Servers			
Model #	Description	Ship Weight	Ship Dimensions
750	Hand Pump Lift	475	L 62" W 57" H 80"
750-A	AIR Power Lift	498	L 62" W 57" H 80"
750-BP	Battery Power Lift	525	L 62" W 57" H 80"




Roll the Pallet-Server to the side of the pallet. Pivot the lifting mechanism to the left or right to reach a drum in any position on the pallet. Use the Pallet Server to lift your drum clear of the pallet. You can pick or place all four drums, one at a time, with access from only one side of the pallet.

Move an upright drum. The operator holds no weight and does not need to balance the drum pallet server.

Note: Disconnect air line on model 750-A to travel with Pallet Server holding your drum.





Other Drum Palletizers

Simply wheel the Drum Spotter up to the corner of the pallet with the handle raised, and the two lifting hooks will slide under the top rim of your drum. Pull down the handle to lift the drum and it's ready to be wheeled away. The Drum-Spotter is designed for rimmed 55-gallon (210 liter) steel or plastic drums weighing up to 800 Lb. (363 kg).

Model 81 Drum Spotter

Moves your drums to and from corners of pallets. Serves a 6" high pallet.



This ergonomic drum palletizer is equipped with battery powered lift for ease of use. Approach the corner of a pallet to push the jaws below the rim of your drum, then use the single control to raise it. The jaws automatically grip the drum rim on the way up. Set the drum down, and the jaws release when the weight is removed.

Model 82H-125 Drum Palletizer

Move your drums to and from the corners of a pallet with battery-power lift. Raises drum 20" off the floor.

